

MAKE: TOYOTA **TYPE:** Landcruiser 40 Series
MODEL: BJ40, FJ40, HJ40 **YEAR:** 1960 - 1980
DETAIL: SWB
 25mm Spring Eye



TOY-50

TOYOTA

FRONT		QTY	PART NUMBER
<p>LEAF SPRING Single Stage</p> <p>25mm Spring Eye</p> <p>7 Leaves Raised Height (45mm Lift)</p>		2	HJ40-7L-F
<p>7 Leaves Raised Height (45mm Lift) 200Kg Accessories (Bull Bar and Winch)</p>		2	HJ45-7L-F
<p>SHACKLE BUSH KIT</p> <p>Kit Contains: 12 x SPF2230</p>		1	PB59-1013K
<p>U-BOLT KIT</p> <p>Right Hand Side Kit Contains: 1 x UB59-453-1 1 x UB59-453-3</p>		1	UB59-450K
<p>Left Hand Side Kit Contains: 2 x UB59-453-3</p>		1	UB59-453-3K
<p>SHOCK ABSORBER</p> <p>Heavy Duty Twin Tube Gas</p>		2	GS59-635
<p>STEERING DAMPER</p> <p>Heavy Duty (Big Bore) Complete with Fittings</p>		1	SD59-823
<p>SHACKLE KIT</p> <p>Greasable: Fit in Pairs</p>		2	SK59-002
<p>PIN KIT</p> <p>Greasable: Fit in Pairs</p>		2	SP59-006

REAR		QTY	PART NUMBER
<p>LEAF SPRING Two Stage</p> <p>25mm Spring Eye</p> <p>6 Leaves Raised Height (45mm Lift) 25mm Longer Main Leaf</p>		2	TOY-034-R
<p>7 Leaves Raised Height (50mm Lift) 150Kg to GVM 25mm Longer Main Leaf</p>		2	TOY-029-R
<p>SHACKLE BUSH KIT</p> <p>Kit Contains: 12 x SPF2230</p>		1	PB59-1013K
<p>U-BOLT KIT</p> <p>Kit Contains: 2 x UB59-453-3</p>		2	UB59-453-3K
<p>SHOCK ABSORBER</p> <p>Pre 01/1975 Heavy Duty Twin Tube Gas</p>		2	GS59-635
<p>01/1975 on Heavy Duty Twin Tube Gas</p>		2	GS59-636
<p>SHACKLE KIT</p> <p>Greasable: Fit in Pairs</p>		2	SK59-002
<p>PIN KIT</p> <p>Greasable: Fit in Pairs</p>		2	SP59-006