

**MAKE:** TOYOTA **TYPE:** Landcruiser 70 Series

**MODEL:** LJ70, LJ72, LJ73, LJ77, **YEAR:** 01/1990 - 05/1993  
(RJ70, RJ73, KZJ 70/73 - 1994 on)

**DETAIL:** Square Headlights



TOY-65

TOYOTA

FRONT	QTY	PART NUMBER
<b>COIL SPRING</b>		
Linear Rate Raised Height (40mm Lift) Up to 50Kg Accessories (Bull Bar OR Winch)	1	<b>C59-288</b> (B)
Linear Rate Super Raised Height (60mm Lift) Up to 50Kg Accessories (Bull Bar and Winch) (Recommended)	1	<b>C59-244</b> (B)
<div style="border: 1px solid black; padding: 2px;"> <span style="color: blue;">i</span> Fit Long travel shock absorber GS59-634 with the above spring.                     </div>		
<b>SHOCK ABSORBER</b>		
Heavy Duty Twin Tube Gas	2	<b>GS59-632</b>
<div style="border: 1px solid black; padding: 2px;"> <span style="color: red;">x</span> To be used with original Toyota springs <b>OR</b> C59-288                     </div>		
Heavy Duty Twin Tube Gas Long Travel	2	<b>GS59-634</b>
<div style="border: 1px solid black; padding: 2px;"> <span style="color: blue;">i</span> Can only be used with C59-244                     </div>		
<b>STEERING DAMPER</b>		
Heavy Duty (Big Bore) Complete with Fittings	1	<b>SD59-824</b>
<b>UNDER BODY BUSH KIT</b>		
See Rear Under Body Bush Kit		
<b>CASTOR KIT</b>		
Front Radius Arm Castor Kit ( $\pm 2^\circ$ )		
4 x Polyurethane Bushes 4 x Eccentric Bushes (+1 Grease Tube)	1	<b>SPF1721K</b>
<div style="border: 1px solid black; padding: 2px;">                     Raising vehicle will effect castor angle.                      A wheel alignment is recommended to determine if a castor kit is required.                 </div>		
<b>ADJUSTABLE PANHARD RODS</b>		
Left Hand Drive Complete with Bushes	1	<b>PR59-1408</b>

REAR	QTY	PART NUMBER
<b>COIL SPRING</b>		
Linear Rate Raised Height (40mm Lift) (Recommended)	1	<b>C59-289</b> (B)
Linear Rate Super Raised Height (65mm Lift) Medium Load to GVM	1	<b>C59-247</b> (B)
<div style="border: 1px solid black; padding: 2px;"> <span style="color: blue;">i</span> Fit Long travel shock absorber GS59-633 with the above spring.                     </div>		
<b>SHOCK ABSORBER</b>		
Heavy Duty Twin Tube Gas	2	<b>GS59-631</b>
<div style="border: 1px solid black; padding: 2px;"> <span style="color: red;">x</span> To be used with original Toyota springs <b>OR</b> C59-289                     </div>		
Heavy Duty Twin Tube Gas Long Travel	2	<b>GS59-633</b>
<div style="border: 1px solid black; padding: 2px;"> <span style="color: blue;">i</span> Can only be used with C59-247                     </div>		
<b>UNDER BODY BUSH KIT</b>		
Kit Includes Front & Rear Under Body Bushes		
2 x Front Radius Rod to Chassis Bush 4 x Front Radius Rod to Diff Bush 2 x Front Panhard Rod Bush 2 x Rear Radius Rod to Chassis Bush 4 x Rear Radius Rod to Diff Bush 2 x Rear Panhard Rod Bush	1	<b>PB59-1260K</b>