



TOYOTA

MAKE: TOYOTA **TYPE:** Landcruiser
MODEL: SWB - FZJ71, HZJ71 **YEAR:** 1999 - 2004
 MWB - FZJ74, HZJ74
DETAIL: LWB - FZJ76, HZJ76



TOY-87

FRONT	QTY	PART NUMBER	REAR	QTY	PART NUMBER
<p style="text-align: center;">COIL SPRING</p>  <p style="text-align: center;">Linear Rate Standard Height</p>			<p style="text-align: center;">LEAF SPRING Single Stage</p> 		
<p style="text-align: center;">1</p>			<p style="text-align: center;">Price Code </p> <p style="text-align: center;">(if applicable)</p>		
<p style="text-align: center;">Linear Rate Standard Height</p>			<p style="text-align: center;">FZJ/HZJ 71 SWB 7 Leaves Plus 1 Spacer Leaf 1 L59-071-R RH Raised Height (50mm Lift) 1 L59-071-R LH</p>		
<p style="text-align: center;">Linear Rate Raised Height (50mm Lift) Comfort Option</p>			<p style="text-align: center;">FZJ/HZJ 74 MWB 7 Leaves Plus 1 Spacer Leaf 1 L59-074-R RH Raised Height (50mm Lift) 1 L59-074-R LH</p>		
<p style="text-align: center;">Up to 50 Kg Accessories (Bullbar OR Winch)</p>			<p style="text-align: center;">FZJ/HZJ 76 LWB 8 Leaves Raised Height (50mm Lift) 1 L59-076-R RH 250Kg to GVM 1 L59-076-R LH</p>		
<p style="text-align: center;">Linear Rate Raised Height (50mm Lift) Up to 50 Kg Accessories (Bullbar OR Winch)</p>			<p style="text-align: center;">SHACKLE BUSH KIT</p>  <p style="text-align: center;">Kit Contains: 4 x SPF1781 2 x SPF1782 4 x SPF1798</p>		
<p style="text-align: center;">Linear Rate Raised Height (50mm Lift) Super Heavy Duty 50 - 100Kg Accessories (Bullbar and Winch)</p>			<p style="text-align: center;">1 PB59-1090K</p>		
<p style="text-align: center;">SHOCK ABSORBER</p> 			<p style="text-align: center;">U-BOLT KIT</p>  <p style="text-align: center;">Kit Contains: 2 x UB59-453-3</p>		
<p style="text-align: center;">2 GS45-114</p>			<p style="text-align: center;">2 UB59-453-3K</p>		
<p style="text-align: center;">STEERING DAMPER</p> 			<p style="text-align: center;">SHOCK ABSORBER</p> 		
<p style="text-align: center;">1 SD59-824</p>			<p style="text-align: center;">Heavy Duty Twin Tube Gas Light Load 2 GS59-649 Heavy Duty Twin Tube Gas 2 GS59-650 Heavy Duty Twin Tube Gas Big Bore 2 GS59-651</p>		
<p style="text-align: center;">UNDER BODY BUSH KIT</p>  <p style="text-align: center;">Kit Includes Front Under Body Bushes</p>			<p style="text-align: center;">SHACKLE KIT</p>  <p style="text-align: center;">Greasable: Fit in Pairs 2 SK59-051</p>		
<p style="text-align: center;">2 x Front Panhard Rod Bush 2 x Front Leading Arm to Diff Bush 4 x Front Leading Arm to Chassis Bush</p>			<p style="text-align: center;">PIN KIT</p>  <p style="text-align: center;">Greasable: Fit in Pairs 2 SP59-044</p>		
<p style="text-align: center;">1 PB59-1261K</p>			<p style="text-align: center;">1 SPF1721K</p>		
<p style="text-align: center;">CASTOR KIT</p> <p style="text-align: center;">Front Radius Arm Castor Kit (±2°)</p>			<p style="text-align: center;">Raising vehicle will effect castor angle. A wheel alignment is recommended to determine if a castor kit is required.</p>		
<p style="text-align: center;">4 x Polyurethane Bushes 4 x Eccentric Bushes (+1 Grease Tube)</p>					